Model Quatech USBN-500

4-Port USB 2.0 Device Server over IP

Quick Installation Guide

- The default IP of this USB device server is 192.168.3.22
- If you need to change IP of this device server, please set up your PC as 192.168.3.XXX where XXX is a different number from 22.
- After set up your PC IP, then open a web page, and type http://192.168.3.22 to reach the Logon page. Username is “admin”, and password is “usbip”.
- At top of the web page, you will see “Home”, “Network”, “Status”, “Upgrade”, “Log”, and “Thank”. Please click on “Network”.
- When inside “Network” option, you will see DHCP with default as “DISABLE”. You can change it to “ENABLE” and click “submit”, and then the USB device server’s IP address becomes DHCP type.
- For more detailed setup & functions of this device server, please refer to User’s Manual.